

Assembly Guide

Tool Holder for Cleaning Trolleys

583018 (Ø22 mm clamp) + 583019 (Ø28 mm clamp)



Place the flat mounting piece so that it fits into the top rail of the bracket.



Press down and the mounting piece will click into the bottom rail.



Keep the tool clamp open and insert the "wings" on the back of the clamp into the matching holes on the mounting piece.



The complete holder is now ready to mount on your trolley.